



Pre-Installation Checklist

- ☐ The following are needed for the installation:
 - DV609 Kit
 - □ DV607 Module
 - □ DV607PHAR
 - □ DV610
 - ☐ TIE1001
 - ☐ TOOLS1081 (Torx wrench)
 - □ DV608 (SIM/SD side cover)
 - □ DV610 for replacement only
 - □ DV676
 - ☐ SWI6027



(DV6 SD/SIM SIDE COVER, REPLACMENT REQUIRED FOR DV6 BATCHES RELEASED PRIOR TO WEEK 46/2022)




TOOL1081

(T5/T8 TORX WRENCH PROVIDED W/ DV6)


Quick Start Guide:

DV609 Video Converter KIT




DV607 MODULE

DV607PHAR (POWER HARNESS)



TIF1001

(2x ZIP TIES FOR SECURING HARNESSES. CHECK 3b)



(RELAY HARNESS KIT)

OPENING THE DV6:

- Use the provided TOOL1081 (T8) from DV6 box to remove SD/SIM side cover from the DV6. Note: If you still have the old side cover [FIG. A], the replacement for a new side cover DV608 is needed [FIG. B]
 - b. Peel off black sticker on the VX cover to reveal T5 screw.
 - Use TOOL1081 (T5) to loosen the screw and remove the VX cover completely. [FIG. D]

CONNECTING DV607 HSD HARNESS WITH DV6:

- a. Place mini-USB connector of DV676 cable on SD/SIM side cover slot. [FIG. E] Press mini-USB connector all the way down to the bottom of slot and make sure the white arrow is facing up.
 - b. Insert the mini-USB connector with the SD/SIM side cover into VX port of DV6. [FIG. F & FIG. G] Note: Make sure the mini-USB connection is secure in the VX port before closing the side cover. [FIG. H]
 - Completely close the SD/SIM side cover with power harness up. [FIG. J]



Old SD/SIM Side Cover



FIG. C



New SD/SIM Side Cover (DV608)




FIG. H




PREPERATION & ROUTING HARNESSES

- a. Loosen panels necessary to run harnesses from Camera and DV6 TO DV607.
- b. Find a location for DV607 in the vehicle.
- c. Route DV676 harness from DV6 to DV607, then connect HSD connector to DV607 video out. [FIG. K]
- d. Connect 4-Pin video input connector to DV607 [FIG. L]
- e. Connect 2-Pin connector of DV607PHAR power harness to DV607 [FIG. M]









MOUNTING DV607 WITH ZIP TIE OR

#10 SCREWS (NOT INCLUDED) AND SECURING HARNESSES WITH ZIP TIES (PROVIDED -TIE1001)

- After all harnesses are connected and secured on DV607, find an available cables or surfaces to mount DV607 with zip ties [FIG. N1] or #10 screws. [FIG. O]
- b. Use provided zip ties as shown in [FIG.N2] to secure harnesses.

 ZIP TIE OR SCREWS






NOT PROVIDED

DV607 POWER WIRING W/ RELAY HARNESS (SWI6027)

- a. Connect 2-Pin female connector of DV676 to 2-Pin male connector of SWI6027. [FIG. T]
- b. Find the vehicle power(BATT) wire. Install provided TTAP connector from SWI6027 (Red:22-18 AWG, Blue:16-14 AWG, Yellow:12 AWG) on power wire with plier. [FIG. R]
- c. Connect a spade connector of SWI6027 power wire to the TTAP on the vehicle power wire. [FIG. S]
- d. Connect white wire of SWI6027 to power wire of DV607PHAR. [FIG. T]








POWER UP DV6 AND CHECK LED STATUS

- a. Start the vehicle ignition to power up DV6 and DV607
 - b. Check LED status on DV6 and make sure green LED is solid.[FIG. P]
- c. Check LED status on DV607 and make sure both green LED and blue LED are solid. [FIG. Q]



ENABLE CHANNEL 3

Channel 3 is enabled via Installer App. Check and confirm Channel 3 images after it's installed. [FIG. U] or [FIG. V]





FIG. U (Mounted as a side-camera)

FIG. V (Mounted camera internally)

7 SECURE THE CONNECTION (MOUNT SIDE COVER: DV608)

 a. Tighten two side cover screws using provided torx wrench (T8). [FIG. W]



FIG. W

For additional help with installation, please contact Rosco Support:

T: (718) 526-2601

E: techsupport@roscovision.com

W: www.roscolive.com